

2K Primer Surfacer

Delta® DPS306

DPS306 2K Primer Surfacer is a fast-dry surfacer intended for use in the fleet market, where spot repairs are common. DPS306 may be applied directly to most substrates and is chrome and lead free.



Features

- High Solids
- User Friendly
- Easy to Sand

Advantages

- Fast Build
- Fast Dry

Benefits

- Increased Productivity
- Saves Labor

Compatible Surfaces

Delta® DPS306 may be applied over:

- Cured and sanded OEM finishes
- Properly cleaned and sanded fiberglass
- Properly cleaned and sanded: steel, aluminum and stainless
- Galvanized and Galvaneal steel must be primed with DX1787 or DX1793 before applying DPS306
- DEP351 3.5 Epoxy Primer
- DPU217 2.1 VOC Polyurethane
- DX1793 Chrome-Free, Self-Etching Primer
- DPHS52 Low VOC Primer
- DPU166 High Solids Chromate Primer 2.8 VOC Max.
- DPU174 High Solids Polyurethane Primer (Chrome-Free)
- DX1787 Etching Filler

If sanding bare metal areas prior to the application of DPS306, use 180-240 grit wet or dry.
Sand old finishes with 240-280 grit wet or dry.

Prime aluminum, stainless and carbonated steel immediately after cleaning and sanding.

Catalyst

Catalyst for DPS306

DPS307

DPS306

Application Guide

Preparation:



- Wash the area to be painted with soap and water, and then clean with DX436 or DX437 wax and grease remover. DX438 Low VOC Cleaner should be used in VOC restricted areas.
- Aluminum and steel substrates need to be sanded with 80 - 180 grit wet or dry. Re-clean with DX436, DX437 or DX438.
- Sand harder metal substrates, such as stainless steel or galvanized steel with 180 - 240 grit wet or dry. Re-clean with DX436, DX437, or DX438.
- Prime aluminum, stainless and carbon steel immediately after cleaning.

Mixing Ratio:



DPS306	DPS307
3 parts	1 part

Pot life:



1½ hours @ 70°F and 50% RH
(High heat and humidity will shorten pot life)

Additives:



Not Recommended

Spraygun set-up:



Fluid Tip: 1.2 - 1.4 mm Pressure Feed/HVLP
1.4 - 1.6 mm Conventional Feed/HVLP

Air Pressure: HVLP at air cap 10 PSI
Conventional at spray gun 45 - 50 PSI

Consult the Fleet Training Manual Spray Equipment section for gun set-up requirements.

Number of coats:



1 - 3 wet coats

Total film build per coat:

	Wet	Dry
Minimum	2.8 mils	2.0 mils
Maximum	8.3 mils	6.0 mils

Flash Time at 70°F (21°C):

Between coats

5 - 10 minute

Drying times:

	Air Dry @ 70°F	Force Dry**
Dust:	10 minutes	10 minutes
Tack:	20-30 minutes	20 minutes @ 130°F
Tape:	1-2 hours	10 minutes @ 160°F
Dry to Sand:	1-2 hours	After cool down
Dry to Topcoat:	30 minutes	

Note: After 8 hours, DPS306 must be sanded before additional primer or topcoat can be applied.

** Force drying times are for quoted surface temperature. Additional time should be allowed in the force-drying schedule to allow surface to reach recommended temperature.

Test Properties:

Color	Yellow Oxide
VOC DPS306 Packaged	3.4 lbs. per U.S. gal
VOC DPS307 Packaged	2.8 lbs. per U.S. gal. (1.5 less exempt solvents)
VOC RTS Applied	3.3 lbs. per U.S. gal. (2.9 less exempt solvents)
Volume Solids (RTS)	53.8%
Square Foot Coverage	864 sq. ft.
(RTS US Gallon 100% Transfer Efficiency)	

Compatible Topcoats:

DPHS52 Low VOC Primer
 DELTA® (DSS) Medium Solids Polyurethane
 DELTA® (DFHS) Fast Dry High Solids Polyurethane
 DELTA® (DUHS) High Solids Polyurethane
 DELTA® (DUHS) Basecoat
 DELTA® (DVHS) Fast Dry 2.8 VOC Polyurethane
 DELTA® (DGHS) Chemical Resistant Polyurethane 3.5 VOC
 DELTA® (DGHS) Chemical Resistant Polyurethane 4.4 VOC
 DELTA® (DHS) 2.8 VOC Polyurethane
 DEP351 DELTA® 3.5 Epoxy Primer
 DPU174 High Solids Polyurethane Primer
 DPU217 DELTA® 2.1 VOC Polyurethane Primer







Health and Safety

See Material Safety Data Sheet and Labels for additional safety information and handling instructions.
 Emergency Medical or Spill Control Information
 (304) 843-1300; In Canada (514) 645-1320

Delta® DPS306

2K Primer Surfacer

Instant Reference

How to Mix:		DPS306 3 parts	DPS307 1 part
Pot life:		Pot life @ 70°F and 50% RH: 1½ hours	
Additives:		Not Recommended	
Gun set-up:		HVLP: Conventional: Fluid Tip:	10 PSI at the air cap 45 - 50 PSI at the gun 1.2 - 1.4 mm for Pressure Feed/HVLP 1.4 - 1.6 mm for Conventional Feed/HVLP
Application:		Apply: Film build per coat: Minimum Maximum	1 - 3 wet coats <i>Wet</i> 2.8 mils 8.3 mils <i>Dry</i> 2.0 mils 6.0 mils
Drying times:			Air Dry @ 70°F Force Dry Purge 20 minutes @ 70°F Between Coats: 5-10 minutes Dust: 10 minutes Tack: 20-30 minutes Tape: 1-2 hours Dry to Sand: 1-2 hours Dry to Topcoat: 30 minutes

For additional information, refer back to the complete FL306 bulletin.

EMERGENCY MEDICAL OR SPILL CONTROL INFORMATION (304) 843-1300. IN CANADA (514) 645-1320. Materials described are designed for application by professional, trained personnel using proper equipment and are not intended for sale to the public. Products mentioned may be hazardous and should only be used according to directions, while observing precautions and warning statements listed on label. Statements and methods described are based upon the best information and practices known to PPG Industries. Procedures for applications mentioned are suggestions only and are not to be construed as representations or warranties as to performance, results, or fitness for any intended use, nor does PPG Industries warrant freedom from patent infringement in the use of any formula or process set forth herein.



World leaders in automotive finishes

Fleet

PPG Industries
19699 Progress Dr.
Strongsville, OH 44149

PPG Canada Inc.
1330 Castlefield Avenue
Toronto, Ontario M6B 4B3